


GBR





Pos	Code	Description	NOTE	Q.
1	GBR.001	Main body		1
2	GB97-86-1-2	Pin		1
3	GBR.002	Middle Arm		1
4	GBR.003	Side Arm		2
5	GB97-86-2	Pin		1
6	GB97-86-3	Bolt		1
7	GB97-86-4	Bottom Pin		1
8	GB97-86-5	Washer		1
9	GB97-86-6	Plain Washer		1
10	GB97-86-7-2	Nut		1
11	GBR.004.4	Blade GBR 120		1
11	GBR.004.6	Blade GBR 180		1
11	GBR.004.7	Blade GBR 210		1
12	GB97-86-8	Pin		1
13	GB97-86-9-2	Pin		1
14	GBR.005.4	Blade Body GBR 120		1
14	GBR.005.6	Blade Body GBR 180		1
14	GBR.005.7	Blade Body GBR 210		1
15	GB97-86-10-2	nut		1
16	GB97-86-11	Washer		1
17	GB97-86-12	Plain Washer		1
18	GBR.006	Blade Support		1
19	GB97-86-13	R Pin		1
20	GB97-86-14	Bushing		1
21	GBR.007	Main Pin		1