


ECO 8



# ECO 8






| Pos | Code      | Description            | NOTE | Q. |
|-----|-----------|------------------------|------|----|
| 1   | ECO8F.01  | frame                  |      | 1  |
| 2   | ECO8F.02  | pin                    |      | 2  |
| 3   | ECO8F.03  | emergency switch box   |      | 1  |
| 4   | ECO8F.04  | emergency switch       |      | 1  |
| 5   | ECO8F.05  | bolt                   |      | 2  |
| 6   | ECO8F.06  | handle                 |      | 1  |
| 7   | JF420     | engine JF420           |      | 1  |
| 8   | ECO8F.08  | hopper                 |      | 1  |
| 9   | ECO8F.09  | rubber cover           |      | 1  |
| 10  | ECO8F.010 | strip 3mm              |      | 1  |
| 11  | ECO8F.011 | washer M6              |      | 6  |
| 12  | ECO8F.012 | bolt M6                |      | 6  |
| 13  | ECO8F.013 | lock washer            |      | 1  |
| 14  | ECO8F.014 | cap Bearing            |      | 1  |
| 15  | ECO8F.015 | Bearing House          |      | 2  |
| 16  | ECO8F.016 | bearing                |      | 2  |
| 17  | ECO8F.017 | rotor                  |      | 1  |
| 18  | ECO8F.018 | blade                  |      | 2  |
| 19  | ECO8F.019 | washer                 |      | 5  |
| 20  | ECO8F.020 | special bolt for blade |      | 5  |
| 21  | ECO8F.021 | shredder box           |      | 1  |
| 22  | ECO8F.022 | top of the box         |      | 1  |
| 23  | ECO8F.023 | washer                 |      | 2  |
| 24  | ECO8F.024 | bolt                   |      | 2  |
| 25  | ECO8F.025 | conveyer               |      | 1  |

| Pos | Code      | Description               | NOTE | Q. |
|-----|-----------|---------------------------|------|----|
| 26  | ECO8F.026 | bolt for counter blade    |      | 5  |
| 27  | ECO8F.027 | bolt special              |      | 1  |
| 28  | ECO8F.028 | deflector                 |      | 1  |
| 29  | ECO8F.029 | rotor key                 |      | 1  |
| 30  | ECO8F.030 | locking washer M8         |      | 6  |
| 31  | ECO8F.031 | washer                    |      | 14 |
| 32  | ECO8F.032 | bolt                      |      | 14 |
| 33  | ECO8F.033 | bolt for bearing housing  |      | 8  |
| 34  | ECO8F.034 | locking washer M6         |      | 2  |
| 35  | ECO8F.035 | belt cover                |      | 1  |
| 36  | ECO8F.036 | washer                    |      | 8  |
| 37  | ECO8F.037 | bolt                      |      | 8  |
| 38  | ECO8F.038 | V belt A1780-13x1750L-A69 |      | 2  |
| 39  | ECO8F.039 | belt pulley 146           |      | 1  |
| 40  | ECO8F.040 | key for rotor             |      | 1  |
| 41  | ECO8F.041 | screw                     |      | 4  |
| 42  | ECO8F.042 | safety ring for Rotor     |      | 1  |
| 43  | ECO8F.043 | belt cover - top          |      | 1  |
| 44  | ECO8F.044 | safety ring for engine    |      | 1  |
| 45  | ECO8F.045 | key                       |      | 1  |
| 46  | ECO8F.046 | belt pulley               |      | 1  |
| 47  | ECO8F.047 | cap for wheel             |      | 1  |
| 48  | ECO8F.048 | spacer                    |      | 4  |
| 49  | ECO8F.049 | wheel                     |      | 2  |
| 50  | ECO8F.050 | axle                      |      | 1  |

| Pos | Code          | Description          | NOTE | Q. |
|-----|---------------|----------------------|------|----|
| 51  | ECO8F.051     | safety switch        |      | 1  |
| 52  | ECO8F.052     | counter blade        |      | 1  |
| 53  | ECO8F.053     | bolt                 |      | 2  |
| 54  | ECO8F.054     | cover of the muffler |      | 1  |
| 55  | ECO8F.055     | bumper               |      | 1  |
| 56  | ECO7.01.127   | Engine_bolt M8x40    |      | 1  |
| 57  | GB5287-8x28x3 | WASHER 8x28x3        |      | 1  |

# ECO 8FMH





| Pos | Code           | Description            | NOTE | Q. |
|-----|----------------|------------------------|------|----|
| 1   | SZ27.011       | bottom housing         |      | 1  |
| 2   | SZ27.013       | knife rotor            |      | 1  |
| 3   | UCFU205        | bearing UCFU 205       |      | 2  |
| 4   | SZ27.102       | knife                  |      | 2  |
| 5   | SZ27.101       | counter knife          |      | 1  |
| 6   | SZ27.015       | linkage                |      | 1  |
| 7   | SZ27.016       | discharge chute- lower |      | 0  |
| 8   | SZ27.014       | feed hopper            |      | 1  |
| 9   | GB70.3-M12X20  | bolt M12X20            |      | 8  |
| 10  | GB70.1-M10x20  | Bolt M10X20            |      | 4  |
| 11  | GB97.1-8       | Plain washer 8         |      | 26 |
| 12  | GB889.1-M8     | Locking nut M8         |      | 21 |
| 13  | GB97.1-10      | PLAIN WASHER 10        |      | 16 |
| 14  | GB93-10        | spring washer 10       |      | 10 |
| 15  | GB5783-M10x30  | Bolt M10X30            |      | 9  |
| 16  | GB5783-M8x20   | bolt M8X20             |      | 8  |
| 17  | GB93-8         | Spring washer 8        |      | 11 |
| 18  | GB5783-M10x20  | Bolt M10x20            |      | 2  |
| 19  | SZ27.103       | bearing guarder        |      | 1  |
| 20  | SZ27.104       | hopper guarder         |      | 1  |
| 21  | SZ27.105       | plate                  |      | 1  |
| 22  | GB1096-A8x7x40 | key A8X7X40            |      | 1  |
| 23  | SZ27.108       | belt pulley            |      | 1  |
| 24  | SZ27.019       | cover                  |      | 1  |
| 25  | GB97.1-9x28x3  | washer 9X28X3          |      | 1  |

| Pos | Code           | Description                        | NOTE | Q. |
|-----|----------------|------------------------------------|------|----|
| 26  | GB1171-B1854Li | belt B1854 Li                      |      | 2  |
| 27  | 1011A101       | Assembly- Discharge Chute          |      | 0  |
| 28  | SZ27.012       | base frame                         |      | 1  |
| 29  | JF420          | engine JF420                       |      | 1  |
| 30  | SZ27.106       | axle                               |      | 1  |
| 31  | SZ27.018       | wheel assy 13X5-6                  |      | 2  |
| 32  | GB276-6002Z    | bearing 6002Z                      |      | 4  |
| 33  | GB889.1-M10    | Locking nut M10                    |      | 8  |
| 34  | GB5783-M10x75  | bolt M10X75                        |      | 4  |
| 35  | GB5783-M10x45  | Bolt M10X45                        |      | 4  |
| 36  | GB96-10x30x2.5 | washer 10X30X2.5                   |      | 4  |
| 37  | SZ27.022       | clutch pulley                      |      | 1  |
| 38  | GB1096-A7x7x50 | key A7X7X50                        |      | 1  |
| 39  | AT120.114      | Spacer Washer for Pulley 2 grooves |      | 1  |
| 40  | SZ27.017       | front hitch                        |      | 1  |
| 41  | GB5782-M8x50   | Bolt M8X50                         |      | 2  |
| 42  | SZ27.107       | bush                               |      | 2  |
| 43  | GB6170-M10     | Nut 10                             |      | 3  |
| 44  | 7-16-20x1.5UNF | bolt 7-16-20x1.5UNF                |      | 1  |
| 45  | GB93-12        | spring washer 12                   |      | 1  |
| 46  | GB97.1-12      | plain washer 12                    |      | 1  |
| 47  | GB5783-M8x25   | bolt M8X25                         |      | 8  |
| 48  | SZ27.109       | support                            |      | 1  |
| 49  | GB5783-M8x16   | bolt M8X16                         |      | 6  |
| 50  | SZ27.110       | support plate                      |      | 1  |

| Pos | Code       | Description                    | NOTE | Q. |
|-----|------------|--------------------------------|------|----|
| 51  | SZ27.020   | leg                            |      | 1  |
| 52  | SZ27.021   | handrail                       |      | 1  |
| 53  | SZ27.023   | stop button                    |      | 1  |
| 54  | SZ27.00.01 | Spacer Counter-knife Width=2mm |      | 1  |
| 55  | SZ27.00.02 | Spacer Counter-knife Width=4mm |      | 1  |


# OTORE JF340-390-420



# Air cleaner


14

15




| Pos | Code       | Description             | NOTE | Q. |
|-----|------------|-------------------------|------|----|
| 1   | JF340-O-01 | AIR CLEANER COVER NUT   |      | 2  |
| 2   | JF340-O-02 | AIR CLEANER COVER       |      | 1  |
| 3   | JF340-O-03 | AIR CLEANER GROMMER     |      | 1  |
| 4   | JF340-O-04 | AIR CLEANER ELEMENT     |      | 1  |
| 5   | JF340-O-05 | OUTER FILTER            |      | 1  |
| 6   | JF340-O-06 | SILENCER NOSE           |      | 1  |
| 7   | JF340-O-07 | ELBOW PACKING           |      | 1  |
| 8   | JF340-O-08 | FLANGE BOLT (M6×20)     |      | 1  |
| 9   | JF340-O-09 | AIR CLEANER COLLAR      |      | 1  |
| 10  | JF340-O-10 | AIR CLEANER ELBOW COMP. |      | 1  |
| 11  | JF340-O-11 | AIR CLEANER COLLAR      |      | 1  |
| 12  | JF340-O-12 | FLANGE NUT (M8)         |      | 2  |
| 13  | JF340-O-13 | AIR CLEANER ASSY.       |      | 1  |
| 14  | JF340-O-14 | COMPLETE AIR FILTER     |      | 1  |

# Fan cover system assy.



| Pos | Code       | Description              | NOTE | Q. |
|-----|------------|--------------------------|------|----|
| 1   | JF340-H-01 | SHROUD                   |      | 1  |
| 2   | JF340-H-02 | FLANGE BOLT (M6×14)      |      | 6  |
| 3   | JF340-H-03 | FAN COVER COMP.          |      | 1  |
| 4   | JF340-H-04 | CORD CLAMPER             |      | 1  |
| 5   | JF340-H-05 | ENGINE STOP SWITCH ASSY. |      | 1  |


# Flywheel system Assy.



| Pos | Code        | Description          | NOTE | Q. |
|-----|-------------|----------------------|------|----|
| 1   | JF340-J-01A | FLYWHEEL             |      | 1  |
| 2   | JF340-J-01B | FLYWHEEL             |      | 1  |
| 3   | JF340-J-02  | SPECIAL WOODRUFF KEY |      | 1  |
| 4   | JF340-J-03  | COOLING FAN          |      | 1  |
| 5   | JF340-J-04  | STARTER PULLEY       |      | 1  |
| 6   | JF340-J-05  | FLYWHEEL NUT (M16)   |      | 1  |

# Fuel tank system assy.


16



| Pos | Code       | Description             | NOTE | Q. |
|-----|------------|-------------------------|------|----|
| 1   | JF340-P-01 | FUEL TANK ASSY.         |      | 1  |
| 2   | JF340-P-02 | FLANGE BOLT (M8×25)     |      | 2  |
| 3   | JF340-P-03 | SUPPORTER RUBBER        |      | 1  |
| 4   | JF340-P-04 | TUBE CLIP               |      | 2  |
| 5   | JF340-P-05 | FUEL TUBE               |      | 1  |
| 6   | JF340-P-06 | O-RING (14mm)           |      | 1  |
| 7   | JF340-P-07 | FUEL TANK JOINT         |      | 1  |
| 8   | JF340-P-08 | FLANGE NUT (M6)         |      | 1  |
| 9   | JF340-P-09 | FUEL FILTER             |      | 1  |
| 10  | JF168-N-11 | FUEL FILLER CAP PACKING |      | 1  |
| 11  | JF340-P-10 | FUEL FILLER CAP COMP.   |      | 1  |

# Ignition System Assy.


11



| Pos | Code       | Description             | NOTE | Q. |
|-----|------------|-------------------------|------|----|
| 1   | JF340-K-01 | PLENUM CAP              |      | 1  |
| 3   | JF340-K-03 | STOP SWITCH CORD        |      | 1  |
| 4   | JF340-K-04 | STOP SWITCH CORD HOLDER |      | 1  |
| 5   | JF340-K-05 | FLANGE BOLT (M6×25)     |      | 2  |
| 6   | JF340-K-06 | CORD GROMMENT           |      | 1  |
| 7   | JF340-K-07 | CHARGE COIL ASSY.       |      | 1  |
| 8   | JF340-K-08 | FLANGE BOLT (M6×40)     |      | 2  |
| 9   | JF340-K-09 | CORD CLAMPER            |      | 1  |
| 10  | JF340-K-10 | FLANGE BOLT (M6×20)     |      | 1  |

# Muffler System Assy.


14



| Pos | Code       | Description             | NOTE | Q. |
|-----|------------|-------------------------|------|----|
| 1   | JF340-N-01 | TAPPING SCREW (M5×8)    |      | 4  |
| 2   | JF340-N-02 | MUFFLER PROTECTOR COMP. |      | 1  |
| 3   | JF340-N-03 | MUFFLER COMP.           |      | 1  |
| 4   | JF340-N-04 | SPARK ARRESTER (SILENT) |      | 1  |
| 5   | JF340-N-05 | EX. PIPE GASKET         |      | 1  |
| 6   | JF340-N-06 | EX. PIPE COMP.          |      | 1  |
| 7   | JF340-N-07 | MUFFLER GASKET          |      | 1  |
| 8   | JF340-N-08 | FLANGE NUT (M8)         |      | 2  |
| 9   | JF240-N-09 | MUFFLER ASSY.           |      | 1  |


# Piston and connecting rod system assy.

5



| Pos | Code       | Description             | NOTE | Q. |
|-----|------------|-------------------------|------|----|
| 1   | JF340-E-01 | COMPRESSION RING A      |      | 1  |
| 2   | JF340-E-02 | COMPRESSION RING B      |      | 1  |
| 3   | JF340-E-03 | OIL RING A              |      | 2  |
| 4   | JF340-E-04 | OIL RING B              |      | 1  |
| 5   | JF240-E-05 | PISTON PIN CLIP (20 mm) |      | 2  |
| 6   | JF340-E-05 | PISTON                  |      | 1  |
| 7   | JF340-E-06 | PISTON PIN              |      | 1  |
| 8   | JF340-E-07 | CONNECTING ROD          |      | 1  |
| 9   | JF340-E-08 | CONNECTING COVER        |      | 1  |
| 10  | JF340-E-09 | CONNECTING ROD BOLT     |      | 2  |
| 11  | JF340-E-10 | PISTON RING SET         |      | 1  |


## 7



| Pos | Code       | Description               | NOTE | Q. |
|-----|------------|---------------------------|------|----|
| 1   | JF340-G-01 | RECOIL STARTER ASSY.      |      | 1  |
| 2   | JF340-G-02 | CENTER SCREW              |      | 1  |
| 3   | JF340-G-03 | SPRING RETAINER           |      | 1  |
| 4   | JF340-G-04 | FRICTION SPRING           |      | 1  |
| 5   | JF340-G-05 | STARTER RATCHET           |      | 2  |
| 6   | JF340-G-06 | RATCHET SPRING            |      | 2  |
| 7   | JF340-G-07 | RECOIL STARTER REEL       |      | 1  |
| 8   | JF340-G-08 | START RETURN SPRING       |      | 1  |
| 9   | JF340-G-09 | RECOIL STARTER CASE COMP. |      | 1  |
| 10  | JF340-G-10 | RECOIL STARTER ROPE       |      | 1  |
| 11  | JF340-G-11 | STARTER GRIP              |      | 1  |
| 12  | JF340-G-12 | FLANGE BOLT (M6×8)        |      | 3  |

# Starter motor System assy.


12



| Pos | Code       | Description         | NOTE | Q. |
|-----|------------|---------------------|------|----|
| 1   | JF340-L-01 | UNIT STARTER MOTOR  |      | 1  |
| 2   | JF340-L-02 | CONTACTOR ASSY.     |      | 1  |
| 3   | JF340-L-03 | FLANGE BOLT (M8×35) |      | 2  |

# Camshaft system assy.


6



| Pos | Code       | Description               | NOTE | Q. |
|-----|------------|---------------------------|------|----|
| 1   | JF340-F-01 | LOCKNUT                   |      | 2  |
| 2   | JF340-F-02 | ADJUSTING NUT             |      | 2  |
| 3   | JF340-F-03 | ROCKER ARM                |      | 2  |
| 4   | JF340-F-04 | ROCKER BOLT (8 mm)        |      | 2  |
| 5   | JF340-F-05 | PUSH ROD GUIDE PLATE      |      | 1  |
| 6   | JF240-F-06 | ROD PUSH                  |      | 2  |
| 7   | JF240-F-07 | CAM FOLLOWER              |      | 2  |
| 8   | JF270-F-08 | CAMSHAFT                  |      | 1  |
| 9   | JF340-F-06 | EX. VALVE HELMET          |      | 1  |
| 10  | JF340-F-07 | EX. VALVE SPRING RETAINER |      | 1  |
| 11  | JF340-F-08 | VALVE SPRING              |      | 2  |
| 12  | JF340-F-09 | VALVE SPRING SEAT         |      | 2  |
| 13  | JF340-F-10 | IN. VALVE SPRING RETAINER |      | 1  |
| 14  | JF340-F-11 | EX. VALVE                 |      | 1  |
| 15  | JF340-F-12 | IN. VALVE                 |      | 1  |
| 16  | JF340-F-13 | ROCKER ASSY.              |      | 1  |

# Carburetor system assy.


9



| Pos | Code        | Description                 | NOTE | Q. |
|-----|-------------|-----------------------------|------|----|
| 1   | JF340-I-01  | INTAKE PIPE GASKET          |      | 1  |
| 2   | JF340-I-02  | CARBURETOR INSULATING PLATE |      | 1  |
| 3   | JF340-I-03  | CARBURETOR PAPER GASKET     |      | 1  |
| 4   | JF340-I-04A | CARBURETOR ASSY.            |      | 1  |
| 5   | JF340-I-05  | CARBURETOR IRON GASKET      |      | 1  |

# Control box assy.


17



| Pos | Code       | Description       | NOTE | Q. |
|-----|------------|-------------------|------|----|
| 1   | JF390-Q-01 | CONTROL BOX ASSY. |      | 1  |

# Control System Assy.


13



| Pos | Code        | Description              | NOTE | Q. |
|-----|-------------|--------------------------|------|----|
| 1   | JF340-M-01A | CONTROL ASSY.            |      | 1  |
| 2   | JF340-M-02A | CONTROL BASE COMP.       |      | 1  |
| 3   | JF340-M-03  | CONTROL ADJUSTING SPRING |      | 1  |
| 4   | JF340-M-04  | CROSS POND SCREW (M5×34) |      | 1  |
| 5   | JF340-M-05  | FLANGE BOLT (M6×14)      |      | 1  |
| 6   | JF340-M-06  | GOVERNOR SPRING          |      | 1  |
| 7   | JF340-M-07  | THROTTLE RETURN SPRING   |      | 1  |
| 8   | JF340-M-08  | GOVERNOR ROD             |      | 1  |
| 9   | JF340-M-09  | FLANGE NUT (M6)          |      | 1  |
| 10  | JF340-M-10  | GOVERNOR ARM BOLT (M6)   |      | 1  |
| 11  | JF340-M-11  | CONTROL ARM              |      | 1  |

# Crankcase cover system assy.


3



| Pos | Code        | Description                   | NOTE | Q. |
|-----|-------------|-------------------------------|------|----|
| 1   | JF340-B-11  | OIL SEAL (diam 35× diam 52×8) |      | 1  |
| 2   | JF340-C-01  | FLANGE BOLT (M8×35)           |      | 7  |
| 3   | JF340-C-02A | OIL SCALE                     |      | 2  |
| 4   | JF340-C-03  | OIL SCALE SEAL RING           |      | 2  |
| 5   | JF340-C-04A | CRANKCASE COVER               |      | 1  |
| 6   | JF340-B-04  | BALL BEARING (6207)           |      | 1  |
| 7   | JF340-B-13  | BALL BEARING (6202)           |      | 1  |
| 8   | JF340-C-05  | SLIDER SHAFT                  |      | 1  |
| 9   | JF340-C-06  | GOVERNOR GEAR WASHER (6 mm)   |      | 1  |
| 10  | JF340-C-07  | GOVERNOR GEAR                 |      | 1  |
| 11  | JF340-C-08  | SLIDER WASHER (6 mm)          |      | 1  |
| 12  | JF340-C-09  | GOVERNOR SLIDER               |      | 1  |
| 13  | JF340-C-10  | CRANKCASE COVER PAD           |      | 1  |
| 14  | JF240-C-11  | DOWEL PIN (8×12)              |      | 2  |

# Crankshaft system assy.


4



| Pos | Code       | Description      | NOTE | Q. |
|-----|------------|------------------|------|----|
| 1   | JF340-D-01 | CRANK            |      | 1  |
| 2   | JF340-D-02 | CRANKSHAFT COMP. |      | 1  |
| 3   | JF340-D-03 | BALANCE SHAFT    |      | 1  |

# Cylinder barrel


2



| Pos | Code       | Description                   | NOTE | Q. |
|-----|------------|-------------------------------|------|----|
| 1   | JF340-B-01 | FLANGE BOLT (M6×14)           |      | 3  |
| 2   | JF240-B-02 | OIL LEVEL SWITCH ASSY.        |      | 1  |
| 3   | JF240-B-03 | O-RING (14mm)                 |      | 1  |
| 4   | JF340-B-02 | FLANGE NUT (10 mm)            |      | 1  |
| 5   | JF340-B-03 | CRANK CASE                    |      | 1  |
| 6   | JF340-B-04 | BALL BEARING (6207)           |      | 1  |
| 7   | JF340-B-05 | WASHER (diam 8.3× diam 17×1)  |      | 1  |
| 8   | JF340-B-06 | LOCK PIN (10 mm)              |      | 1  |
| 9   | JF340-B-07 | GOVERNOR ARM SHAFT            |      | 1  |
| 10  | JF340-B-08 | OIL SEAL (diam 8× diam 14×5)  |      | 1  |
| 11  | JF340-B-09 | DRAIN PLUG WASHER (12 mm)     |      | 2  |
| 12  | JF340-B-10 | DRAIN PLUG BOLT               |      | 2  |
| 13  | JF340-B-11 | OIL SEAL (diam 35× diam 52×8) |      | 1  |
| 14  | JF340-B-12 | OIL PROTECTOR                 |      | 1  |
| 15  | JF340-B-13 | BALL BEARING (6202)           |      | 1  |

# Cylinder head system assy.

1



| Pos | Code        | Description                      | NOTE | Q. |
|-----|-------------|----------------------------------|------|----|
| 1   | JF340-A-01  | HEAD COVER COMP. BOLT            |      | 1  |
| 2   | JF340-A-02  | HEAD COVER WASHER COMP.          |      | 1  |
| 3   | JF340-A-03  | WASHER COVER PACKING             |      | 1  |
| 4   | JF340-A-04  | HEAD COVER COMP.                 |      | 1  |
| 5   | JF340-A-05  | HEAD COVER PACKING               |      | 1  |
| 6   | JF340-A-06  | FLANGE BOLT (M10×80)             |      | 4  |
| 7   | JF340-A-07  | SPARK PLUG                       |      | 1  |
| 8   | JF340-A-08A | EXHAUST PIPE STUD BOLT           |      | 2  |
| 9   | JF340-A-09  | CYLINDER HEAD COMP.              |      | 1  |
| 10  | JF340-A-10A | CARBURETOR STUD BOLT             |      | 2  |
| 11  | JF340-A-11  | CYLINDER HEAD SEALING PAD        |      | 1  |
| 12  | JF340-A-12  | DOWE L PIN (diam 10× diam 12×20) |      | 2  |
| 13  | JF340-A-13A | BREATHER TUBE                    |      | 1  |