



PRI_PRM





Pos	Code	Description	NOTE	Q.
1	PRM100-011	Linkage Frame 100		1
1	PRM120-011	Linkage Frame 120		1
1	PRM140-011	Linkage Frame 140		1
1	PRM160-011	Linkage Frame 160		1
2	PRM160-013	Support		1
3	HB14A30	Bolt M14*30		1
4	PRM160-102	Lower Pin		2
5	PRM160-106	Safty Pin		1
6	PRM160-103	Upper Pin		1
7	RP4	R Pin 4		7
8	QCM	Quick Couple		2
9	BW1/2	Quick couple 1/2		2
10	PRI160-104	Oil Pipe		1
11	PRI160-104	Oil Pipe		2
12	HHB14A1.5	Hollow BoltM14*1.5		2
13	BW14	Bonded washer 14		4
14	PRI160-102	Cylinder Lower Pin		1
15	PRI120.140-103	Cylinder		1
15	PRI160-103	Cylinder		1
16	PRI160-101	Cylinder Upper Pin		1
17	PRM100-012	Bucket 100		1
17	PRM120-012	Bucket 120		1
17	PRM140-012	Bucket 140		1
17	PRM160-012	Bucket 160		1
18	PRM160-104	Bucket Pin		2



Pos	Code	Description	NOTE	Q.
1	PRM100-011	Linkage Frame 100		1
1	PRM120-011	Linkage Frame 120		1
1	PRM140-011	Linkage Frame 140		1
1	PRM160-011	Linkage Frame 160		1
2	PRM160-013	Support		1
3	HB14A30	Bolt M14*30		1
4	PRM160-102	Lower Pin		2
5	PRM160-015	Unload Plate		1
6	PRM160-107	Unload Pin		1
7	PRM160-106	Safty Pin		1
8	PRM160-103	Upper Pin		1
9	PRM100-012	Bucket 100		1
9	PRM120-012	Bucket 120		1
9	PRM140-012	Bucket 140		1
9	PRM160-012	Bucket 160		1
10	PRM160-101	Spring		1
11	PRM160-014	Fork		1
12	PRM160-105	Fork Pin		1
13	RP4	R Pin 4		7
14	HB16A60	Bolt M14*60		1
15	PRM160-104	Bucket Pin		2