



PRI\_PRM





| Pos | Code           | Description        | NOTE | Q. |
|-----|----------------|--------------------|------|----|
| 1   | PRM100-011     | Linkage Frame 100  |      | 1  |
| 1   | PRM120-011     | Linkage Frame 120  |      | 1  |
| 1   | PRM140-011     | Linkage Frame 140  |      | 1  |
| 1   | PRM160-011     | Linkage Frame 160  |      | 1  |
| 2   | PRM160-013     | Support            |      | 1  |
| 3   | HB14A30        | Bolt M14*30        |      | 1  |
| 4   | PRM160-102     | Lower Pin          |      | 2  |
| 5   | PRM160-106     | Safty Pin          |      | 1  |
| 6   | PRM160-103     | Upper Pin          |      | 1  |
| 7   | RP4            | R Pin 4            |      | 7  |
| 8   | QCM            | Quick Couple       |      | 2  |
| 9   | BW1/2          | Quick couple 1/2   |      | 2  |
| 10  | PRI160-104     | Oil Pipe           |      | 1  |
| 11  | PRI160-104     | Oil Pipe           |      | 2  |
| 12  | HHB14A1.5      | Hollow BoltM14*1.5 |      | 2  |
| 13  | BW14           | Bonded washer 14   |      | 4  |
| 14  | PRI160-102     | Cylinder Lower Pin |      | 1  |
| 15  | PRI120.140-103 | Cylinder           |      | 1  |
| 15  | PRI160-103     | Cylinder           |      | 1  |
| 16  | PRI160-101     | Cylinder Upper Pin |      | 1  |
| 17  | PRM100-012     | Bucket 100         |      | 1  |
| 17  | PRM120-012     | Bucket 120         |      | 1  |
| 17  | PRM140-012     | Bucket 140         |      | 1  |
| 17  | PRM160-012     | Bucket 160         |      | 1  |
| 18  | PRM160-104     | Bucket Pin         |      | 2  |



| Pos | Code       | Description       | NOTE | Q. |
|-----|------------|-------------------|------|----|
| 1   | PRM100-011 | Linkage Frame 100 |      | 1  |
| 1   | PRM120-011 | Linkage Frame 120 |      | 1  |
| 1   | PRM140-011 | Linkage Frame 140 |      | 1  |
| 1   | PRM160-011 | Linkage Frame 160 |      | 1  |
| 2   | PRM160-013 | Support           |      | 1  |
| 3   | HB14A30    | Bolt M14*30       |      | 1  |
| 4   | PRM160-102 | Lower Pin         |      | 2  |
| 5   | PRM160-015 | Unload Plate      |      | 1  |
| 6   | PRM160-107 | Unload Pin        |      | 1  |
| 7   | PRM160-106 | Safty Pin         |      | 1  |
| 8   | PRM160-103 | Upper Pin         |      | 1  |
| 9   | PRM100-012 | Bucket 100        |      | 1  |
| 9   | PRM120-012 | Bucket 120        |      | 1  |
| 9   | PRM140-012 | Bucket 140        |      | 1  |
| 9   | PRM160-012 | Bucket 160        |      | 1  |
| 10  | PRM160-101 | Spring            |      | 1  |
| 11  | PRM160-014 | Fork              |      | 1  |
| 12  | PRM160-105 | Fork Pin          |      | 1  |
| 13  | RP4        | R Pin 4           |      | 7  |
| 14  | HB16A60    | Bolt M14*60       |      | 1  |
| 15  | PRM160-104 | Bucket Pin        |      | 2  |