

MD




# MD 300



Dumper




Garden




| Pos | Code      | Description              | NOTE | Q. |
|-----|-----------|--------------------------|------|----|
| 1   | MD.01.001 | bolt                     |      | 8  |
| 2   | MD.01.002 | Gear Support             |      | 1  |
| 3   | MD.01.003 | track Tensioner Assembly |      | 2  |
| 4   | MD.01.004 | washer                   |      | 1  |
| 5   | MD.01.005 | nut                      |      | 1  |
| 6   | MD.01.006 | Screw                    |      | 6  |
| 7   | MD.01.007 | wheel Track              |      | 8  |
| 8   | MD.01.008 | Bolt                     |      | 6  |
| 9   | MD.01.009 | Bolt                     |      | 4  |
| 10  | MD.01.010 | bolt                     |      | 8  |
| 11  | MD.01.011 | spring washer            |      | 6  |
| 12  | MD.01.012 | Rubber Cap               |      | 6  |
| 13  | MD.01.013 | Cover                    |      | 1  |
| 14  | MD.01.014 | Main Frame               |      | 1  |
| 15  | MD.01.015 | washer                   |      | 8  |
| 16  | MD.01.016 | washer                   |      | 8  |
| 17  | MD.01.017 | Support                  |      | 1  |
| 18  | MD.01.018 | support                  |      | 1  |
| 19  | MD.01.019 | nut                      |      | 2  |
| 20  | MD.01.020 | nut                      |      | 2  |
| 21  | MD.01.021 | washer                   |      | 4  |
| 22  | MD.01.022 | pin                      |      | 4  |
| 23  | MD.01.023 | Spacer                   |      | 2  |
| 24  | MD.01.024 | Belt Cover Lower         |      | 1  |
| 25  | MD.01.025 | rubber track             |      | 2  |


| Pos | Code      | Description        | NOTE | Q. |
|-----|-----------|--------------------|------|----|
| 26  | MD.01.026 | plate R            |      | 1  |
| 27  | MD.01.027 | plate L            |      | 1  |
| 28  | MD.01.028 | Gas Spring Lifter  |      | 1  |
| 29  | MD.01.029 | Bolt               |      | 1  |
| 30  | MD.01.030 | Belt Cover Upper   |      | 1  |
| 31  | MD.01.031 | plate              |      | 1  |
| 32  | MD.01.032 | pin                |      | 1  |
| 33  | MD.01.033 | axle               |      | 2  |
| 34  | MD.01.034 | spacer             |      | 2  |
| 35  | MD.01.035 | Bolt PIN           |      | 2  |
| 36  | MD.01.036 | Transmission Cover |      | 1  |
| 37  | MD.01.037 | Spacer             |      | 4  |
| 38  | MD.01.038 | screw bolt         |      | 4  |
| 39  | MD.01.039 | washer             |      | 4  |
| 40  | MD.01.040 | bolt               |      | 4  |




| Pos | Code      | Description       | NOTE | Q. |
|-----|-----------|-------------------|------|----|
| 1   | MD.02.001 | Tensioner Support |      | 1  |
| 2   | MD.02.002 | cover             |      | 2  |
| 3   | MD.02.003 | washer            |      | 2  |
| 4   | MD.02.004 | nut               |      | 2  |
| 5   | MD.02.005 | spring Washer     |      | 2  |
| 6   | MD.02.006 | Wheel Tensioner   |      | 1  |
| 7   | MD.02.007 | bearing           |      | 2  |
| 8   | MD.02.008 | axle              |      | 1  |
| 9   | MD.02.009 | seeger            |      | 1  |
| 10  | MD.02.010 | bearing           |      | 1  |




| Pos | Code      | Description   | NOTE | Q. |
|-----|-----------|---------------|------|----|
| 1   | MD.03.001 | axle          |      | 1  |
| 2   | MD.03.002 | Wheel Track   |      | 2  |
| 3   | MD.03.003 | bearing       |      | 2  |
| 4   | MD.03.004 | spacer        |      | 2  |
| 5   | MD.03.005 | cover         |      | 2  |
| 6   | MD.03.006 | washer        |      | 2  |
| 7   | MD.03.007 | nut           |      | 2  |
| 8   | MD.03.008 | spring washer |      | 2  |




| Pos | Code      | Description      | NOTE | Q. |
|-----|-----------|------------------|------|----|
| 1   | MD.04.001 | handle L         |      | 1  |
| 2   | MD.04.002 | handle R         |      | 1  |
| 3   | MD.04.003 | handle support L |      | 1  |
| 4   | MD.04.004 | handle support R |      | 1  |
| 5   | MD.04.005 | bolt             |      | 6  |
| 6   | MD.04.006 | spring washer    |      | 6  |
| 7   | MD.04.007 | washer           |      | 6  |
| 8   | MD.04.008 | bolt             |      | 6  |
| 9   | MD.04.009 | bolt             |      | 2  |
| 10  | MD.04.010 | washer           |      | 4  |
| 11  | MD.04.011 | nut              |      | 4  |
| 12  | MD.04.012 | spring washer    |      | 4  |
| 13  | MD.04.013 | nut              |      | 1  |
| 14  | MD.04.014 | safety handle    |      | 1  |
| 15  | MD.04.015 | plate            |      | 1  |
| 16  | MD.04.016 | handle dial      |      | 2  |
| 17  | MD.04.017 | throttle         |      | 1  |
| 18  | MD.04.018 | cable            |      | 1  |
| 19  | MD.04.019 | rubber handle    |      | 1  |



| Pos | Code      | Description  | NOTE | Q. |
|-----|-----------|--------------|------|----|
| 1   | MD.05.001 | support      |      | 1  |
| 2   | MD.05.002 | handle       |      | 1  |
| 3   | MD.05.003 | handle block |      | 1  |
| 4   | MD.05.004 | spring       |      | 1  |
| 5   | MD.05.005 | pin          |      | 1  |
| 6   | MD.05.006 | Cable        |      | 1  |





| Pos | Code      | Description  | NOTE | Q. |
|-----|-----------|--------------|------|----|
| 1   | MD.06.001 | handle frame |      | 1  |
| 2   | MD.06.002 | handle       |      | 1  |
| 3   | MD.06.003 | special bolt |      | 1  |
| 4   | MD.06.004 | spacer       |      | 1  |
| 5   | MD.06.005 | ring         |      | 1  |
| 6   | MD.06.006 | bolt         |      | 1  |
| 7   | MD.06.007 | seeger       |      | 1  |
| 8   | MD.06.008 | spline       |      | 1  |
| 9   | MD.06.009 | nut          |      | 1  |
| 10  | MD.06.010 | cable        |      | 1  |




| Pos | Code      | Description          | NOTE | Q. |
|-----|-----------|----------------------|------|----|
| 1   | MD.07.001 | Transmission Gearbox |      | 1  |
| 2   | MD.07.002 | plate L              |      | 1  |
| 3   | MD.07.003 | plate R              |      | 1  |
| 4   | MD.07.004 | pin                  |      | 2  |
| 5   | MD.07.005 | small pin            |      | 2  |
| 6   | MD.07.006 | spring               |      | 1  |
| 7   | MD.07.007 | Gear Handle          |      | 1  |
| 8   | MD.07.008 | Cap                  |      | 1  |
| 9   | MD.07.009 | switch Handle        |      | 1  |
| 10  | MD.07.010 | nut                  |      | 2  |
| 11  | MD.07.011 | bolt                 |      | 2  |
| 12  | MD.07.012 | cap                  |      | 1  |
| 13  | MD.07.013 | key                  |      | 1  |
| 14  | MD.07.014 | bolt                 |      | 2  |
| 15  | MD.07.015 | washer               |      | 2  |
| 16  | MD.07.016 | washer               |      | 4  |
| 17  | MD.07.017 | nut                  |      | 2  |
| 18  | MD.07.018 | pin                  |      | 2  |
| 19  | MD.07.019 | Big Gear             |      | 2  |
| 20  | MD.07.020 | pulley               |      | 1  |
| 21  | MD.07.021 | bolt                 |      | 1  |
| 22  | MD.07.022 | nut                  |      | 4  |
| 23  | MD.07.023 | plate                |      | 1  |
| 25  | MD.07.025 | washer               |      | 2  |
| 26  | MD.07.026 | bolt                 |      | 1  |


| Pos | Code      | Description   | NOTE | Q. |
|-----|-----------|---------------|------|----|
| 27  | MD.07.027 | plate         |      | 1  |
| 28  | MD.07.028 | washer        |      | 2  |
| 29  | MD.07.029 | R pin         |      | 2  |
| 30  | MD.07.030 | nut           |      | 2  |
| 31  | MD.07.031 | spacer        |      | 2  |
| 32  | MD.07.032 | spring washer |      | 2  |
| 33  | MD.07.033 | washer        |      | 4  |
| 34  | MD.07.034 | support       |      | 1  |
| 35  | MD.07.035 | cover         |      | 1  |
| 36  | MD.07.036 | bolt          |      | 2  |



| Pos | Code      | Description          | NOTE | Q. |
|-----|-----------|----------------------|------|----|
| 1   | MD.07.001 | Transmission Gearbox |      | 1  |
| 2   | MD.07.002 | plate L              |      | 1  |
| 3   | MD.07.003 | plate R              |      | 1  |
| 4   | MD.07.004 | pin                  |      | 1  |
| 5   | MD.07.005 | small pin            |      | 2  |
| 6   | MD.07.006 | spring               |      | 1  |
| 7   | MD.07.007 | Gear Handle          |      | 2  |




| Pos | Code        | Description          | NOTE | Q. |
|-----|-------------|----------------------|------|----|
| 1   | MD.008.001G | nut                  |      | 1  |
| 2   | MD.008.002G | base plate           |      | 1  |
| 3   | MD.008.003G | front plate          |      | 1  |
| 4   | MD.008.004G | back plate           |      | 1  |
| 5   | MD.008.005G | left plate           |      | 1  |
| 6   | MD.008.006G | right plate          |      | 1  |
| 7   | MD.008.007G | bolt                 |      | 2  |
| 8   | MD.008.008G | washer               |      | 2  |
| 9   | MD.008.009G | spring               |      | 1  |
| 10  | MD.008.010G | plate                |      | 1  |
| 11  | MD.008.011G | bolt                 |      | 1  |
| 12  | MD.008.012G | pin                  |      | 2  |
| 13  | MD.008.013G | rubber cap           |      | 4  |
| 14  | MD.008.014G | spacer               |      | 2  |
| 16  | MD.008.016G | washer               |      | 2  |
| 17  | MD.008.017G | bolt                 |      | 2  |
| 18  | MD.008.018G | nut                  |      | 2  |
| 19  | MD.008.019G | hook                 |      | 2  |
| 20  | MD.008.020G | washer               |      | 2  |
| 21  | MD.07.001   | Transmission Gearbox |      | 1  |
| 22  | MD.07.002   | plate L              |      | 1  |
| 23  | MD.07.003   | plate R              |      | 1  |



| Pos | Code         | Description        | NOTE | Q. |
|-----|--------------|--------------------|------|----|
| 1   | MD300.09.001 | centrifugal pulley |      | 1  |
| 2   | MD300.09.002 | Engne JF200        |      | 1  |
| 3   | MD300.09.003 | bolt               |      | 4  |
| 4   | MD300.09.004 | washer             |      | 6  |
| 5   | MD300.09.005 | washer             |      | 1  |
| 6   | MD300.09.006 | nut                |      | 6  |
| 7   | MD300.09.007 | spring washer      |      | 1  |
| 8   | MD300.09.008 | belt               |      | 1  |
| 9   | MD300.09.009 | spacer             |      | 4  |
| 10  | MD300.09.010 | engine bolt        |      | 1  |
| 11  | MD300.09.011 | key                |      | 1  |

# MD 500






| Pos | Code         | Description              | NOTE | Q. |
|-----|--------------|--------------------------|------|----|
| 1   | MD.01.014    | Main Frame               |      | 1  |
| 2   | MD.01.007    | wheel Track              |      | 8  |
| 3   | MD.01.002    | Gear Support             |      | 1  |
| 4   | MD.01.017    | Support                  |      | 1  |
| 5   | MD.01.003    | track Tensioner Assembly |      | 2  |
| 6   | MD.01.035    | Bolt PIN                 |      | 2  |
| 7   | MD.01.001    | bolt                     |      | 8  |
| 8   | MD.01.006    | Screw                    |      | 6  |
| 9   | MD.01.012    | Rubber Cap               |      | 6  |
| 10  | MD.01.004    | washer                   |      | 1  |
| 11  | MD.01.011    | spring washer            |      | 6  |
| 12  | MD.01.019    | nut                      |      | 2  |
| 13  | MD.01.033    | axle                     |      | 2  |
| 14  | MD.01.021    | washer                   |      | 4  |
| 15  | MD.01.022    | pin                      |      | 4  |
| 16  | MD.01.024    | Belt Cover Lower         |      | 1  |
| 17  | MD.01.020    | nut                      |      | 2  |
| 18  | MD.01.005    | nut                      |      | 1  |
| 19  | MD.01.010    | bolt                     |      | 8  |
| 20  | MD.01.025    | rubber track             |      | 2  |
| 21  | MD500.01.021 | washer                   |      | 2  |
| 22  | MD500.01.022 | plate                    |      | 1  |
| 23  | MD500.01.023 | bolt                     |      | 2  |
| 24  | MD500.01.024 | pin axle                 |      | 1  |
| 25  | MD500.01.025 | seeger                   |      | 2  |


| Pos | Code         | Description        | NOTE | Q. |
|-----|--------------|--------------------|------|----|
| 26  | MD500.01.026 | washer             |      | 4  |
| 27  | MD.01.023    | Spacer             |      | 2  |
| 28  | MD.01.034    | spacer             |      | 2  |
| 29  | MD.01.015    | washer             |      | 8  |
| 30  | MD500.01.030 | cover              |      | 1  |
| 31  | MD500.01.031 | bolt               |      | 6  |
| 32  | MD.01.026    | plate R            |      | 1  |
| 33  | MD.01.027    | plate L            |      | 1  |
| 34  | MD500.01.034 | Grease Nipple      |      | 1  |
| 35  | MD.01.036    | Transmission Cover |      | 1  |
| 36  | MD500.01.036 | Cylinder MD500     |      | 1  |
| 37  | MD.01.037    | Spacer             |      | 4  |
| 38  | MD.01.038    | screw bolt         |      | 4  |
| 39  | MD.01.040    | bolt               |      | 4  |
| 40  | MD.01.039    | washer             |      | 4  |
| 41  | MD500.01.041 | Rubber Cap         |      | 4  |

# PART 2




| Pos | Code      | Description       | NOTE | Q. |
|-----|-----------|-------------------|------|----|
| 1   | MD.02.001 | Tensioner Support |      | 1  |
| 2   | MD.02.002 | cover             |      | 2  |
| 3   | MD.02.003 | washer            |      | 2  |
| 4   | MD.02.004 | nut               |      | 2  |
| 5   | MD.02.005 | spring Washer     |      | 2  |
| 6   | MD.02.006 | Wheel Tensioner   |      | 1  |
| 7   | MD.02.007 | bearing           |      | 2  |
| 8   | MD.02.008 | axle              |      | 1  |
| 9   | MD.02.009 | seeger            |      | 1  |
| 10  | MD.02.010 | bearing           |      | 1  |


PART 3




| Pos | Code      | Description   | NOTE | Q. |
|-----|-----------|---------------|------|----|
| 1   | MD.03.001 | axle          |      | 1  |
| 2   | MD.03.002 | Wheel Track   |      | 2  |
| 3   | MD.03.003 | bearing       |      | 2  |
| 4   | MD.03.004 | spacer        |      | 2  |
| 5   | MD.03.005 | cover         |      | 2  |
| 6   | MD.03.006 | washer        |      | 2  |
| 7   | MD.03.007 | nut           |      | 2  |
| 8   | MD.03.008 | spring washer |      | 2  |




| Pos | Code      | Description      | NOTE | Q. |
|-----|-----------|------------------|------|----|
| 1   | MD.04.001 | handle L         |      | 1  |
| 2   | MD.04.002 | handle R         |      | 1  |
| 3   | MD.04.003 | handle support L |      | 1  |
| 4   | MD.04.004 | handle support R |      | 1  |
| 5   | MD.04.005 | bolt             |      | 6  |
| 6   | MD.04.006 | spring washer    |      | 6  |
| 7   | MD.04.007 | washer           |      | 6  |
| 8   | MD.04.008 | bolt             |      | 6  |
| 9   | MD.04.009 | bolt             |      | 2  |
| 10  | MD.04.010 | washer           |      | 4  |
| 11  | MD.04.011 | nut              |      | 4  |
| 12  | MD.04.012 | spring washer    |      | 4  |
| 13  | MD.04.013 | nut              |      | 1  |
| 14  | MD.04.014 | safety handle    |      | 1  |
| 15  | MD.04.015 | plate            |      | 1  |
| 16  | MD.04.016 | handle dial      |      | 2  |
| 17  | MD.04.017 | throttle         |      | 1  |
| 18  | MD.04.018 | cable            |      | 1  |
| 19  | MD.04.019 | rubber handle    |      | 1  |



| Pos | Code      | Description  | NOTE | Q. |
|-----|-----------|--------------|------|----|
| 1   | MD.05.001 | support      |      | 1  |
| 2   | MD.05.002 | handle       |      | 1  |
| 3   | MD.05.003 | handle block |      | 1  |
| 4   | MD.05.004 | spring       |      | 1  |
| 5   | MD.05.005 | pin          |      | 1  |
| 6   | MD.05.006 | Cable        |      | 1  |




| Pos | Code      | Description  | NOTE | Q. |
|-----|-----------|--------------|------|----|
| 1   | MD.06.001 | handle frame |      | 1  |
| 2   | MD.06.002 | handle       |      | 1  |
| 3   | MD.06.003 | special bolt |      | 1  |
| 4   | MD.06.004 | spacer       |      | 1  |
| 5   | MD.06.005 | ring         |      | 1  |
| 6   | MD.06.006 | bolt         |      | 1  |
| 7   | MD.06.007 | seeger       |      | 1  |
| 8   | MD.06.008 | spline       |      | 1  |
| 9   | MD.06.009 | nut          |      | 1  |
| 10  | MD.06.010 | cable        |      | 1  |





| Pos | Code      | Description          | NOTE | Q. |
|-----|-----------|----------------------|------|----|
| 1   | MD.07.001 | Transmission Gearbox |      | 1  |
| 2   | MD.07.002 | plate L              |      | 1  |
| 3   | MD.07.003 | plate R              |      | 1  |
| 4   | MD.07.004 | pin                  |      | 2  |
| 5   | MD.07.005 | small pin            |      | 2  |
| 6   | MD.07.006 | spring               |      | 1  |
| 7   | MD.07.007 | Gear Handle          |      | 1  |
| 8   | MD.07.008 | Cap                  |      | 1  |
| 9   | MD.07.009 | switch Handle        |      | 1  |
| 10  | MD.07.010 | nut                  |      | 2  |
| 11  | MD.07.011 | bolt                 |      | 2  |
| 12  | MD.07.012 | cap                  |      | 1  |
| 13  | MD.07.013 | key                  |      | 1  |
| 14  | MD.07.014 | bolt                 |      | 2  |
| 15  | MD.07.015 | washer               |      | 2  |
| 16  | MD.07.016 | washer               |      | 4  |
| 17  | MD.07.017 | nut                  |      | 2  |
| 18  | MD.07.018 | pin                  |      | 2  |
| 19  | MD.07.019 | Big Gear             |      | 2  |
| 20  | MD.07.020 | pulley               |      | 1  |
| 21  | MD.07.021 | bolt                 |      | 1  |
| 22  | MD.07.022 | nut                  |      | 4  |
| 23  | MD.07.023 | plate                |      | 1  |
| 25  | MD.07.025 | washer               |      | 2  |
| 26  | MD.07.026 | bolt                 |      | 1  |

| Pos | Code      | Description   | NOTE | Q. |
|-----|-----------|---------------|------|----|
| 27  | MD.07.027 | plate         |      | 1  |
| 28  | MD.07.028 | washer        |      | 2  |
| 29  | MD.07.029 | R pin         |      | 2  |
| 30  | MD.07.030 | nut           |      | 2  |
| 31  | MD.07.031 | spacer        |      | 2  |
| 32  | MD.07.032 | spring washer |      | 2  |
| 33  | MD.07.033 | washer        |      | 4  |
| 34  | MD.07.034 | support       |      | 1  |
| 35  | MD.07.035 | cover         |      | 1  |
| 36  | MD.07.036 | bolt          |      | 2  |




| Pos | Code         | Description | NOTE | Q. |
|-----|--------------|-------------|------|----|
| 1   | MD500.08.001 | oil tank    |      | 1  |
| 2   | MD500.08.002 | filter      |      | 1  |
| 3   | MD500.08.003 | distributor |      | 1  |
| 4   | MD500.08.004 | plate tank  |      | 1  |
| 5   | MD500.08.005 | seal oil    |      | 1  |
| 6   | MD500.08.006 | plate       |      | 1  |
| 7   | MD500.08.007 | spring      |      | 1  |
| 8   | MD500.08.008 | bolt        |      | 1  |
| 9   | MD500.08.009 | washer      |      | 1  |
| 10  | MD500.08.010 | washer      |      | 2  |
| 11  | MD500.08.011 | nut         |      | 1  |
| 12  | MD500.08.012 | oil cap     |      | 1  |
| 13  | MD500.08.013 | washer      |      | 28 |
| 14  | MD500.08.014 | bolt        |      | 28 |
| 15  | MD500.08.015 | nut         |      | 28 |
| 16  | MD500.08.016 | washer hydr |      | 4  |
| 17  | MD500.08.017 | washer hydr |      | 4  |
| 18  | MD500.08.018 | bolt hydr   |      | 4  |
| 19  | MD500.08.019 | bolt hydr   |      | 4  |
| 20  | MD500.08.020 | bolt        |      | 2  |
| 21  | MD500.08.021 | washer      |      | 2  |
| 22  | MD500.08.022 | nut         |      | 2  |
| 23  | MD500.08.023 | bolt        |      | 2  |
| 24  | MD500.08.024 | washer      |      | 1  |
| 25  | MD500.08.025 | cap         |      | 1  |

| Pos | Code         | Description | NOTE | Q. |
|-----|--------------|-------------|------|----|
| 26  | MD500.08.026 | bolt        |      | 4  |
| 27  | MD500.08.027 | plate       |      | 1  |
| 28  | MD500.08.028 | oil pipe 4  |      | 1  |
| 29  | MD500.08.029 | oil pipe 3  |      | 1  |
| 30  | MD500.08.030 | oil pipe 2  |      | 1  |
| 31  | MD500.08.031 | oil pipe 1  |      | 2  |
| 32  | MD500.08.032 | cap         |      | 1  |



| Pos | Code         | Description   | NOTE | Q. |
|-----|--------------|---------------|------|----|
| 1   | MD500.09.001 | Dumper        |      | 1  |
| 2   | MD500.09.002 | bushes        |      | 2  |
| 3   | MD500.09.003 | grease nipple |      | 2  |




| Pos | Code         | Description       | NOTE | Q. |
|-----|--------------|-------------------|------|----|
| 1   | MD500.10.001 | Engine JF270      |      | 1  |
| 2   | MD500.10.002 | engine plate      |      | 1  |
| 3   | MD500.10.003 | rubber connection |      | 1  |
| 4   | MD500.10.004 | plate             |      | 1  |
| 5   | MD500.10.005 | Pump              |      | 1  |
| 6   | MD500.10.006 | pump connection 2 |      | 1  |
| 7   | MD500.10.007 | spring washer     |      | 4  |
| 8   | MD500.10.008 | washer            |      | 4  |
| 9   | MD500.10.009 | bolt              |      | 4  |
| 10  | MD500.10.010 | bolt              |      | 6  |
| 11  | MD500.10.011 | long spacer       |      | 1  |
| 12  | MD500.10.012 | spacer            |      | 4  |
| 13  | MD500.10.013 | washer            |      | 1  |
| 14  | MD500.10.014 | nut               |      | 1  |
| 15  | MD500.10.015 | pump connector    |      | 2  |
| 16  | MD500.10.016 | cover             |      | 1  |
| 17  | MD500.10.017 | side cover        |      | 1  |
| 18  | MD500.10.018 | bolt              |      | 8  |
| 19  | MD500.10.019 | washer            |      | 4  |
| 20  | MD500.10.020 | bolt              |      | 4  |
| 21  | MD500.10.021 | bolt              |      | 4  |
| 22  | MD500.10.022 | belt              |      | 1  |
| 23  | MD500.10.023 | engine bolt       |      | 1  |
| 24  | MD500.10.024 | spacer            |      | 4  |
| 25  | MD500.10.025 | nut               |      | 4  |

| Pos | Code         | Description       | NOTE | Q. |
|-----|--------------|-------------------|------|----|
| 26  | MD500.10.026 | pump connection 1 |      | 1  |
| 27  | MD500.10.027 | plate tensioner   |      | 1  |
| 28  | MD500.10.028 | pulley tensioner  |      | 1  |
| 29  | MD500.10.029 | bearing           |      | 2  |
| 30  | MD500.10.030 | seeger            |      | 1  |
| 31  | MD500.10.031 | seeger            |      | 1  |
| 32  | MD500.10.032 | support           |      | 1  |
| 33  | MD500.10.033 | washer            |      | 1  |
| 34  | MD500.10.034 | spacer            |      | 1  |
| 35  | MD500.10.035 | spring            |      | 1  |
| 36  | MD500.10.036 | washer            |      | 1  |
| 37  | MD500.10.037 | cable             |      | 1  |
| 38  | MD500.10.038 | connector         |      | 1  |
| 39  | MD500.10.039 | oil seal          |      | 1  |
| 40  | MD500.10.040 | oil seal          |      | 1  |
| 41  | MD500.10.041 | washer            |      | 4  |
| 42  | MD500.10.042 | key               |      | 1  |
| 42  | MD500.10.042 | key               |      | 4  |
| 43  | MD500.10.043 | bolt              |      | 4  |
| 44  | MD500.10.044 | grease nipple     |      | 1  |


# MD 500 ECO






| Pos | Code          | Description       | NOTE | Q. |
|-----|---------------|-------------------|------|----|
| 1   | MD500.ECO.001 | main frame        |      | 1  |
| 2   | MD500.ECO.002 | Dumper Support    |      | 1  |
| 3   | MD500.ECO.003 | tool Box          |      | 1  |
| 4   | MD500.ECO.004 | Light Assembly    |      | 1  |
| 5   | MD500.ECO.005 | Handle Assembly   |      | 1  |
| 6   | MD500.ECO.006 | Rubber Cap        |      | 4  |
| 7   | MD500.ECO.007 | Dumper Hook       |      | 1  |
| 8   | MD500.ECO.008 | Dumper MD500 ECO  |      | 1  |
| 9   | MD500.ECO.009 | Charge connection |      | 1  |
| 10  | MD500.ECO.010 | Handle Support    |      | 4  |
| 11  | MD500.ECO.011 | Support           |      | 2  |
| 12  | MD500.ECO.012 | Gas Spring        |      | 2  |
| 13  | MD500.ECO.013 | Cover             |      | 1  |
| 14  | MD500.ECO.014 | Axle              |      | 1  |
| 15  | MD500.ECO.015 | washer            |      | 1  |
| 16  | MD500.ECO.016 | Seeger            |      | 2  |
| 17  | MD500.ECO.017 | washer            |      | 8  |
| 18  | MD500.ECO.018 | Spring washer     |      | 8  |
| 19  | MD500.ECO.019 | bolt              |      | 8  |
| 20  | MD500.ECO.020 | Spring washer     |      | 12 |
| 21  | MD500.ECO.021 | bolt              |      | 4  |
| 22  | MD500.ECO.022 | washer            |      | 12 |
| 23  | MD500.ECO.023 | Bolt              |      | 12 |
| 24  | MD500.ECO.024 | Bolt              |      | 4  |
| 25  | MD500.ECO.025 | Bolt              |      | 8  |


| Pos | Code          | Description        | NOTE | Q. |
|-----|---------------|--------------------|------|----|
| 26  | MD500.ECO.026 | Nut                |      | 8  |
| 27  | MD500.ECO.027 | Bolt               |      | 12 |
| 28  | MD500.ECO.028 | bolt               |      | 2  |
| 29  | MD500.ECO.029 | bolt               |      | 1  |
| 30  | MD500.ECO.030 | Battery Cover      |      | 1  |
| 31  | MD500.ECO.031 | Battery Assembly   |      | 1  |
| 32  | MD500.ECO.032 | Support L          |      | 1  |
| 33  | MD500.ECO.033 | Wheel Assembly     |      | 1  |
| 34  | MD500.ECO.034 | nut                |      | 1  |
| 35  | MD500.ECO.035 | Grease nipple      |      | 6  |
| 36  | MD500.ECO.036 | Spring             |      | 1  |
| 37  | MD500.ECO.037 | Back Wheel Asembly |      | 1  |




| Pos | Code             | Description          | NOTE | Q. |
|-----|------------------|----------------------|------|----|
| 1   | MD500.ECO.02.001 | Light Frame Weldment |      | 1  |
| 2   | MD500.ECO.02.002 | Bolt                 |      | 2  |
| 3   | MD500.ECO.02.003 | control Box          |      | 1  |
| 4   | MD500.ECO.02.004 | Washer               |      | 4  |
| 5   | MD500.ECO.02.005 | support R            |      | 1  |
| 7   | MD500.ECO.02.007 | Display Support      |      | 1  |
| 8   | MD500.ECO.02.008 | nut                  |      | 1  |
| 9   | MD500.ECO.02.009 | Nut                  |      | 1  |
| 10  | MD500.ECO.02.010 | Washer               |      | 1  |
| 11  | MD500.ECO.02.011 | Screw                |      | 4  |
| 12  | MD500.ECO.02.012 | support L            |      | 1  |
| 13  | MD500.ECO.02.013 | Spring Washer        |      | 4  |
| 14  | MD500.ECO.02.014 | start block          |      | 1  |
| 15  | MD500.ECO.02.015 | Low Cover            |      | 1  |
| 16  | MD500.ECO.02.016 | Light                |      | 1  |



| Pos | Code             | Description     | NOTE | Q. |
|-----|------------------|-----------------|------|----|
| 1   | MD500.ECO.03.001 | Handle Frame    |      | 1  |
| 2   | MD500.ECO.03.002 | Rubber Handle   |      | 1  |
| 3   | MD500.ECO.03.003 | Throttle Handle |      | 1  |
| 4   | MD500.ECO.03.004 | Left Handle     |      | 1  |
| 5   | MD500.ECO.03.005 | Right Handle    |      | 1  |
| 6   | MD500.ECO.03.006 | Cable           |      | 1  |



| Pos | Code             | Description   | NOTE | Q. |
|-----|------------------|---------------|------|----|
| 1   | MD500.ECO.04.001 | Frame         |      | 1  |
| 2   | MD500.ECO.04.002 | Wheel support |      | 2  |
| 3   | MD500.ECO.04.003 | Light Wheel   |      | 2  |
| 4   | MD500.ECO.04.004 | axle          |      | 2  |
| 5   | MD500.ECO.04.005 | Washer        |      | 4  |
| 6   | MD500.ECO.04.006 | Pin           |      | 4  |
| 7   | MD500.ECO.04.007 | Bearing       |      | 2  |
| 8   | MD500.ECO.04.008 | washer        |      | 2  |
| 9   | MD500.ECO.04.009 | nut           |      | 2  |
| 10  | MD500.ECO.04.010 | Cover         |      | 2  |
| 11  | MD500.ECO.04.011 | bearing       |      | 2  |
| 12  | MD500.ECO.04.012 | grease nipple |      | 2  |



| Pos | Code             | Description          | NOTE | Q. |
|-----|------------------|----------------------|------|----|
| 1   | MD500.ECO.05.001 | Electric Engine      |      | 1  |
| 2   | MD500.ECO.05.002 | trasmission Axle L   |      | 1  |
| 3   | MD500.ECO.05.003 | trasmission Axle R   |      | 1  |
| 4   | MD500.ECO.05.004 | washer               |      | 8  |
| 5   | MD500.ECO.05.005 | bolt                 |      | 12 |
| 6   | MD500.ECO.05.006 | Spring Washer        |      | 2  |
| 7   | MD500.ECO.05.007 | key                  |      | 2  |
| 8   | MD500.ECO.05.008 | Nut Axle             |      | 2  |
| 9   | MD500.ECO.05.009 | pin                  |      | 2  |
| 10  | MD500.ECO.05.010 | Spring Washer        |      | 8  |
| 11  | MD500.ECO.05.011 | nut wheel            |      | 8  |
| 12  | MD500.ECO.05.012 | throttle control box |      | 1  |
| 15  | MD500.ECO.05.015 | nut                  |      | 6  |
| 16  | MD500.ECO.05.016 | hub                  |      | 2  |
| 17  | MD500.ECO.05.017 | bolt wheel           |      | 8  |
| 18  | MD500.ECO.05.018 | Wheel                |      | 2  |